

ASD-5 Smoke Alarm

Brief user protocol

1. This detector has 2 interchangeable AAA batteries.
2. **Activate:**
If you insert the 2 batteries correctly, you will hear a multi-tone melody.
Turn the smoke detector on the bottom plate.
Test the alarm: press 2-3 sec test button.
The pulsating test alarm sound stops automatically.
3. **Normal situation:** Red LED flashes 1x per 4-5 minutes.
4. **Signals:**
3 x beep every 40 seconds: detector is contaminated
>> clean the smoke alarm

1 x beep every 40 seconds: battery voltage drops
>> the batteries need to be replaced
5. **IMPORTANT:** Regular maintenance!!

Maintenance =
1 x vacuuming every month at the openings of the smoke detector +
1 x per month for about 2 sec. pressing the test button
[Not necessary to retrieve the detector from the ceiling]
6. **Important:** Please read supplied instructions for additional information.

