

ASD-10Q Smoke Alarm

Brief user protocol



1. This smoke alarm has a **fixed battery**, it can **NOT** be removed.
Only attach the smoke detector with the supplied adhesive strip or mounting material.

2. **Activate:**
Activate the smoke detector within 14 months of the production date.
Place the smoke alarm on base plate;
Turn clockwise till "click"
A three beep sound will indicate activation of the smoke alarm
Test the alarm: press **5 sec** test button
The pulsating test alarm sound stops automatically



3. **Normal situation:** Red LED flashes 1x per 4-5 minutes.

4. **Signals:**
3 x beep every 40 seconds: detector is contaminated
>> clean the smoke alarm

1 x beep every 40 seconds: battery voltage drops

>> If the smoke alarm is older than 10 years, then it needs to be replaced by a new one

5. **Important::** Regular maintenance!!

Maintenance =

1 x vacuuming every month at the openings of the smoke detector +

1 x per month for about **5 sec.** pressing the test button

[Not necessary to retrieve the detector from the ceiling]

6. **Important:** Please read supplied instructions for additional information.