

## ASD-10Q Smoke Alarm

### Brief user protocol

1. This smoke alarm has a **fixed battery**, it can **NOT** be removed.  
Only attach the smoke detector with the supplied adhesive strip or mounting material.
2. **Activate:**  
Activate the smoke detector within 14 months of the production date.  
Place the smoke alarm on base plate;  
Turn clockwise till "click"  
A three beep sound will indicate activation of the smoke alarm  
Test the alarm: press 5 sec test button  
The pulsating test alarm sound stops automatically
3. **Normal situation:** Red LED flashes 1x per 4-5 minutes.
4. **Signals:**  
**3 x beep** every 40 seconds: detector is contaminated  
>> clean the smoke alarm  
  
**1 x beep** every 40 seconds: battery voltage drops  
>> If the smoke alarm is older than 10 years, then it needs to be replaced by a new one
5. **Important::** Regular maintenance!!  
  
Maintenance =  
1 x vacuuming every month at the openings of the smoke detector +  
1 x per month for about 5 sec. pressing the test button  
[Not necessary to retrieve the detector from the ceiling]
6. **Important:** Please read supplied instructions for additional information.

