

## ASD-5 Smoke Alarm

## Brief user protocol

 This detector has 2 interchangeable AAA batteries.
Only attach the smoke detector with the supplied adhesive strip or mounting material



## 2. Activate:

If you insert the 2 batteries correctly, you will hear a multi-tone melody. Turn the smoke detector on the bottom plate. Test the alarm: press **5** sec test button. The pulsating test alarm sound stops automatically.

- 3. Normal situation: Red LED flashes 1x per 4-5 minutes.
- 4. Signals:

**3 x beep** every 40 seconds: detector is contaminated >> <u>clean the smoke alarm</u>

1 x beep every 40 seconds: battery voltage drops >> the batteries need to be replaced

5. **IMPORTANT:** Regular maintenance!!

Maintenance =

1 x vacuuming every month at the openings of the smoke detector + 1 x per month for about **5** sec. pressing the test button [Not necessary to retrieve the detector from the ceiling]

6. **Important:** Please read supplied instructions for additional information.