

## ASD-10QR Smoke Alarm

Wirelessly connectable 10-year smoke detector

### Brief user protocol

- This detector has a **fixed battery**, it can **NOT** be removed.  
Only attach the smoke detector with the supplied adhesive strip or mounting material.
- Activate:** Activate the smoke detector within 14 months of the production date.  
Place detector on base plate; turn clockwise till "click"; a three beep sound will indicate activation of the smoke alarm; test the alarm: press **5 sec** test button  
The pulsating test alarm sound stops automatically
- Normal situation:** Red LED flashes 1x per 4-5 minutes.
- Important:** Regular maintenance!!  
1 x vacuuming every month at the openings of the smoke detector +  
1 x per month for about **5 sec.** pressing the test button  
[Not necessary to retrieve the detector from the ceiling]



### 5. Signals:

Sound signal:	Red LED:	Function:
No signal	Flashes every 320 sec.	Standby mode Periodical automatic self-diagnostics
Long pulsating sound	Flashes every 0.5 sec.	Alarm status
Long lingering sound	Non	1 of the interconnected smoke alarms are in alarm
1 short signal every 40 sec.	Non	Low battery signal. The smoke alarm needs to be replaced.
2 short signals every 4 hour	Non	Low battery signal in one of the interconnected smoke alarms. This smoke alarm needs to be replaced.
3 short signals every 40 sec.	Non	Fault/ smoke chamber contamination
No signal	Flashes every 0.5 sec.	The smoke chamber has been abruptly contaminated and needs to be cleaned.
No signal	Flashes every 10 sec.	HUSH mode (Alarm muting, sensitivity reduction)
Long pulsating sound while pressing the test button.	Flashes every 0.5 sec.	Test mode: De smoke alarm is operates correctly. All interconnected and installed to the base smoke alarms will go to Remote Alarm status in 10 - 30 sec.
3 short signals while pressing the test button.	Flashes every 3 sec.	De smoke alarm does not operate correctly and needs to be replaced.

- When the ASD-10QR is removed from the base (disconnected) after detecting a problem, it gives the sound that belongs to the detected problem.
- The remaining connected ASD-QR smoke alarms will sound two beeps on disconnection (removal from base), up to 4 hours after removal of the ASD-10QR with a battery empty indication.

- Important:** Please read supplied instructions for additional information.